

Recreational Applications

	Approximate Starting Wattage	Approximate Running Wattage	240V required?
Television			
Tube type	300	300	
Flat Screen	120	120	
RV Air Conditioner			
11000 BTU	1600	1010	
13500 BTU	2800	1800	
15000 BTU	3300	2000	
RV Refrigerator	600	180	
Blender	850	400	
Electric Grill (tabletop)	1650	1650	
Slow Cooker	170-270	170-270	
Hair Dryer (1600 watts)	1900	1800	
Microwave Oven (650 watts)	1000	1000	
Coffee Maker	600	600	
Radiant Heater	1300	1300	
Laptop computer	200-250	200-250	
Satelite Receiver	250	250	
Radio	50 to 200	50 to 200	
Two-Way Radio			
12A	360W	360W	
23A	840W	840W	
35A	960W	960W	
Fan (portable)	120	40	
DVD Player	350	350	